



EN

SX-610 TOP-UP[®]

Owner's Guide

Il marchio **Silentsystem**[®] ed il marchio e design delle cuffie **SX-809 Super Power Bass**[®] sono di proprietà di **LEM International S.r.l.**, con sede in Corso Monte Cucco 71/A - 10141 - Torino (TO) | P.IVA 10762880010. Per maggiori informazioni consultare il Database Marchi e Brevetti Italiano <http://www.uibm.gov.it/index.php/marchi/archivio-articoli>.

INTERNATIONAL
SILENTSYSTEM
Keep the Frequency

CONTENTS

<i>Contents</i>	2
<i>Important Safety Instructions</i>	3
<i>Technical Specifications</i>	4
<i>Preservation</i>	4
<i>Cleaning</i>	4
<i>Warranty</i>	4
<i>Components</i>	5
<i>Powering On/Off</i>	6
<i>Channel Selection</i>	6
<i>Battery & Recharging</i>	6
<i>FAQ - Frequently Asked Questions</i>	7
<i>Trademarks & Patents</i>	7

Important Safety Instructions

Proper Use

These headphones have been designed to be used only with Silentsystem® branded devices. LEM International s.r.l. reserves the right not to provide support if malfunctions arise due to improper use.

Before using the headphones, it is advisable to carefully read the instructions. We strongly recommend to retain this manual.

For Your Safety

Please read carefully and observe important safety information listed below.

- Remove the headphones immediately if you feel a sensation of heat or perceive a drop in audio performance;
 - If skin irritation occurs, stop using the headphones;
 - DO NOT throw, drop or let the headphones undergoing a heavy impact;
 - DO NOT make unauthorized modifications to this product.
- DO NOT use the headphones at high volumes for extended periods of time;
1. *To avoid hearing damage, use the headphones at a moderate and comfortable volume level;*
 2. *Turn up the volume gradually until you reach an adequate listening level.*
- DO NOT use headphones if they emit loud and unusual noises. In this case, turn off the headphones and contact LEM International s.r.l.;
 - DO NOT immerse or expose the headphones to water for prolonged periods or wear them while practicing water sports, eg. swimming, water skiing, surfing, etc.;
 - DO NOT expose to heat sources;
 - DO NOT place heavy objects on the device;

EN



Li-ion

The lithium-ion battery built into this model cannot be removed. In case of any malfunctions, please contact LEM International s.r.l. immediately.



Technical Specifications

APower Supply: DC 3.7 V, built-in rechargeable lithium-ion polymer battery

Battery Capacity: 500 mAh

Speakers Driver: Mylar 40mm

Use and Storage Temperature: 5 °C – 35 °C

Weight: 125 grams

Frequency Response: 30-20.000 Hz

Preservation

- When not in use, turn off the headphones;
- If you plan to not using the headphones for some time, please fully charge the battery.

Cleaning

These headphones require periodic cleaning.

LEM International s.r.l. recommends **Norica Plus**® product, which can be freely purchased in pharmacies and parapharmacies (in Italy).

Alternatively, you can clean the headphones with a cotton swab previously dipped in alcohol.

Warranty

This System (in all its components) is covered by a warranty for a period of 12 months starting from the date of purchase.

Components

EN



Pic. 1 - SX 610 Headphones

The Channels Range Switch and the On / Off or Channel Selection Button are located on the right pavilion, identified by the **letter R**, clearly visible at the junction between the pavilion and the upper arch, on the outside of the headset. Consequently, the Volume Adjustment button (with single presses to increase and long press to reduce) and the Charging Connector are located on the left pavilion, identified by the **letter L**.

Powering On/Off

To turn on the headset, simply press and hold the **On/Off Button**; by doing so, the pavilions will light up in a color between Blue, Green, Red, Purple or Yellow based on the last transmission channel used.

Consequently, to switch off, exert the same prolonged pressure on the **On/Off Button**.

Channel Selection

In correspondence with the selected channel on the Silentsystem® transmitter in your possession, in order to listen to what is being broadcasted, it is necessary to select the same channel on the headphones, using the appropriate **Channel Selection Button** (Pic. 1).

Being the button multi-function, requires you to use a single press to access the channel selection mode.

CHANNEL	RGB COLOUR
1	BLUE
2	RED
3	GREEN
4	PURPLE
5	YELLOW
6	BLINKING BLUE
7	BLINKING RED
8	BLINKING GREEN
9	BLINKING PURPLE
10	BLINKING YELLOW

Battery & Recharging

When the built-in battery of the headset is low **(10% of the remaining charge)** the pavilions will flash; it is therefore recommended to proceed with the device recharging.

The headphone is recharged using the cable with proprietary connector (Pic. 2), and **lasts about 4 hours**, while **the actual time of use is between 8 and 10 hours**, in relation to the listening volume. During the charging phase, the LEDs on the pavilions will be on and red in color, and then turn green when charging is complete.

It is advisable to recharge the battery in environments with temperatures between 10 °C and 30 °C. *Charging in other environments may not be as effective.*



Pic. 2 - Charging Cable

* The charging cable may also come with a single proprietary connector; this solution depends on the equipment rented or purchased.

FAQ - Frequently Asked Questions

DOMANDA	RISPOSTA
Can I use the SX-610 with my mobile phone via Bluetooth®?	No, the SX-610 is designed to function exclusively with Silentsystem ® transmitters, which work with RF (Radio Frequency) technology.
Does the SX-610 have a built-in microphone?	No, the SX-610 is designed to function solely as a listening device.

EN

Trademarks & Patents

MARCHIO / BREVETTO	INFORMAZIONI
Trademark SILENTSYSTEM ®	<i>Req. Number</i> 017042045 Playable in any character, size, and color <i>Country:</i> Europe , Italy, Kazakhstan, USA, Costa Rica, China, Hong Kong, Switzerland, Argentina
Trademark SUPER POWER BASS®	<i>Trademark No.</i> 0001633691 <i>Country:</i> Italy